Configuring the core switch requires



Overview

Configuring the Core Switch In this scenario, IP addresses of the interfaces connecting the core switch to the BRASs and firewalls and OSPF need to be conf.

Key Takeaways

Core switch configuration involves setting up VLANs, IP addresses, routing protocols, and interconnections to ensure efficient and secure network traffic flow.


Core Switch Overview

A core switch operates at Layer 3 of the OSI model, combining high-speed switching with routing capabilities to manage traffic within large LANs and between networks. Its main purposes include accelerating data exchange, providing routing between VLANs, and supporting redundancy through protocols like HSRP or VRRP. Core switches are scalable through multiple slots and module types, such as RJ-45, SFP, or 10Gbps modules, which determine port availability and network capacity.

Key Configuration Steps

Initial Setup

Power on the switch and verify hardware integrity. Connect via console using software like PuTTY for SSH or Telnet access. Set a hostname and domain name for identification and management purposes.



© 2026 BAGYOU FIBRE NETWORKS · All rights reserved

VLAN Configuration

Create VLA

Ns for interconnection with BRASs, firewalls, and other network segments.

Assign VLA

N interfaces (VLANIF) and bind them to VPN instances if needed to isolate traffic. Configure access and trunk ports appropriately: access ports for single VLANs, trunk ports for multiple VLANs.

IP Addressing and Routing

Assign I

P addresses to VLANIF interfaces for Layer 3 routing.

Configure OSP

F or other routing protocols to enable dynamic routing between VLANs and external networks.

Specify VP

N instances to separate public network routes from firewall return routes.

Redundancy and Load Balancing

Implement HSR

P or VRRP to provide hot standby and load sharing between core and aggregation switches. Ensure dual-line redundancy to maintain network stability in case of hardware failure.

Security and Management

Set passwords for console, Telnet, and SSH access. Disable unused ports and configure ACLs to control traffic flow. Optionally, configure NetFlow or SNMP for monitoring and traffic analysis.

Verification and Maintenance

Use commands like show vlan brief, show ip route, and ping to verify connectivity and routing. Save the configuration to prevent loss after reboot (write memory or copy running-config startup-config).

Best Practices

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Plan VLA

N and IP addressing schemes carefully to avoid conflicts. Use consistent naming conventions for VLANs, interfaces, and VPN instances. Regularly update firmware and monitor switch performance to maintain reliability.

Document all configurations for troubleshooting and future expansion. By following these steps, a core switch can be configured to provide high-speed, secure, and reliable network connectivity across an enterprise environment, supporting both internal LAN traffic and external network access efficiently.

Article Content

Configuring the Core Switch

In this scenario, IP addresses of the interfaces connecting the core switch to the BRASs and firewalls and OSPF need to be configured on the core switch, so as to implement connectivity between the

8 Steps to configure your network switch

Learn how to setup a network switch with ease. Switches allow you to send and receive information efficiently and securely. Get setup today!

Designing and Configuring the Core Layer with EAPS

Configuring the core switches requires a new EAPS domain with a single EAPS protected VLAN with OSPF forming the backbone IP network. Additional configuration is needed on the aggregation

What Is a Core Switch in Networking?

Unlike access switches, which connect directly to end-user devices, the core switch focuses on aggregating and routing traffic between other switches, minimizing latency and

Exam 350-401 topic 1 question 394 discussion

A network engineer is enabling HTTPS access to the core switch, which requires a certificate to be installed on the switch signed by the corporate certificate authority.

Core Switch Reference Configuration | Validated Solution Guide

The Core Switch Reference Configuration section provides a reference CLI configuration of the core switches as configured previously in this NetConductor Deployment guide.

COM02_Cisco_R01_9

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Use the following configuration for each Cisco switch (Ask MHT engineers whether they are using a core switch for the job or not). If they have core switch installed on jobsite, the configuration is different

The Ultimate Guide to Huawei MA5800 OLT Configuration:

The high-end models also support 2 x 100GE uplink ports, providing massive uplink bandwidth for enterprise core routing and carrier-grade routing reliability . Deployment Scenarios and Configuration

Introduction to Core Switch Configuration

A switch that functions as part of a router and operates at the third layer of the OSI network standard model, the network layer. The most important purpose of the layer 3 switch is to speed up the data

Guide to Basic Switch Configuration | Auvik

What basic switch configuration includes Basic switch configuration can be thought of as the minimum network, port, and security provisioning required for the production deployment of a

SME Network Solution Typical Configuration Examples

Support Documentation Enterprise Network Solution Horizontal Solutions CloudCampus SME Configuration & Commissioning Configuration Examples

MS Layer 3 Switching and Routing

Layer 3 routing capabilities are available on most Cisco Meraki switches. This allows the switches to route traffic between VLANs in a campus network without the need for an additional layer

Core Configuration of a Router and a Switch in Cisco Packet Tracer ...

Berg IT Training - In this CCST and CCNA introductory-level video, I perform a line-by-line core configuration of a Cisco router and a Cisco switch using the command line interface (CLI) in Cisco ...

Basic Cisco Switch Configuration Example in 10 Steps

Unlike other lower class switch vendors (which are plug-and-play), the Cisco switch needs some initial basic configuration in order to enable management, security and some other important features. In

How to Configure a Cisco Switch in 10 Steps

Learn how to Configure a Cisco Switch. Follow along this Step-by-Step guide that will get you using Commands via PuTTY CLI

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Creating a Base Configuration for a Cisco IOS Switch: A Step-by-Step

Learn how to set up a base configuration for network switches. Secure, optimize, and enable remote access with our step-by-step guide.

Understanding the Core Switch: Key Differences and Uses

Explore the core switch''s role as the backbone of your network. Discover key differences, uses, and insights into layer 3 core switch technology.

Core Switch 2/64 V4.1 Installation Guide

Part Number: AA-RS2WC-TE This installation guide provides procedures for setting up, configuring, and managing the Core Switch 2/64 and Core Switch 2/64 power pak.

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Contact Us

Continue your research online:

Website: https://bagyou.es
Technical inquiry: https://bagyou.es/project-enquiry.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved