Configure the fiber optic serial port of the switch



Overview

This tutorial will explain the steps required to configure fiber optics on a Cisco switch and ensure proper connectivity in your network.

Key Takeaways

To configure a fiber optic switch via the serial port, connect the console port to a PC using the appropriate cable and terminal emulation software, then set communication parameters such as baud rate, data bits, parity, and stop bits.

Connecting the Serial Console

Identify the console port on your fiber optic switch.

For Cisco MD

S 9148T, this is an RS-232 console port located on the front panel. Use the correct cable: Typically, a rollover RJ-45-to-RJ-45 cable is supplied. If your PC has a DB-25 serial port, use an RJ-45-to-DB-25 adapter.

Connect to a PC: Attach the adapter to your PC's serial port and connect the other end to the switch console port.

Ensure the P

C supports VT100 terminal emulation.

© 2026 BAGYOU FIBRE NETWORKS · All rights reserved

Terminal Emulation Setup

Use terminal software such as PuTTY, HyperTerminal, or Tera Term. Configure the serial connection with standard parameters: Baud rate: 9600 bps (common default)Data bits: 8Parity: NoneStop bits: 1Flow control: NoneLaunch the terminal session to access the switch CLI for configuration.

Configuring the Switch

Log in to the switch CLI using the terminal session. Set basic switch parameters: HostnameEnable passwordUser passwordIP address for management (if applicable)Configure fiber-optic ports: Ensure the ports are fiber-enabled. Set speed and duplex mode according to network requirements.

Assign ports to the appropriate VLAN if needed. Save configuration: Use the command copy running-config startup-config to store settings in flash memory. Additional ConsiderationsSFP/SFP+ transceivers must match at both ends of the fiber link, and cables should not exceed recommended lengths.

Electrostatic precautions: Wear an ESD wrist strap when handling transceivers and keep connectors clean. Serial device servers like ZLAN9153 can convert RS-232/RS-485 signals to fiber, allowing remote access without modifying host software. Troubleshooting: If the fiber link does not come up, verify transceiver compatibility, port configuration, and cable integrity.

By following these steps, you can establish a reliable serial connection to your fiber optic switch, configure its ports, and integrate it into your network or SAN environment.

Article Content

Hardware Installation Guide for Cisco 8500 Switches

Before you create a network management connection for the switch or connect the switch to the network, you must create a local management connection through a console terminal

Hardware Installation Guide for Cisco 8100 Series Switches

The following table provides the supported port details and operating temperature of the QDD-400G-ZR-S and QDD-400G-ZRP-S optical modules when port side exhaust or port side intake

How to configure fiber optics on a Cisco switch

This tutorial will explain the steps required to configure fiber optics on a Cisco switch and ensure proper connectivity in your network. Configuring a Cisco Switch: Step-by-Step Guide

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Basic Switch Configuration

The Switch Configuration Example and Commands table provides the basic steps and commands in a checklist format to quickly configure a switch for fabric and possible FICON operation.

Dell EMC PowerSwitch S5248F-ON Port Groups

This document provides Dell EMC SmartFabric OS10 Full Switch mode configuration examples for a VxRail 4.7 cluster or a VxRail 7.0 cluster deployment using Dell EMC PowerSwitch S5248F-ON

Troubleshooting Tip: SFP/SFP+ transceivers port/fiber link is not ...

Try to set the speed setting manually on both sides. For example, some higher-end switch models will have speed set to ''auto-module'' by default on the SFP/SFP+ ports, whereas lower-end

Configuring FortiSwitch split ports (phy-mode) in FortiLink mode

Use 10000full for the general 10G interface configuration. If that setting does not work, use 10000cr for copper connections (with copper cables such as 10GBASE-CR) or use 10000sr for fiber connections

Connecting to the Brocade 7840 using the serial connection

Establishing a serial connection Perform the following steps to log in to the device through the serial connection. Verify that the device has completed POST. When POST is complete, the port status

UniFi Switch US-24 Quick Start Guide

This Quick Start Guide is designed to guide you through the installation and show you how to access the Configuration Interface. This Quick Start Guide also includes the warranty terms, and is for use with

Intelligent IoT Solutions

IoT building blocks & gateways, cloud-based device management, automated downtime managers: Lantronix IoT products and services help you connect smart!

Switches: R&S Networks and Cybersecurity

The switch portfolio of R&S Networks and Cybersecurity is the basis for modern network infrastructures in all industries and areas of application. There is a choice of custom-fit versions with Power over

Optic Modules Datasheet

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Features and Benefits The following table lists the different pluggable optic modules and supported platforms, along with the technical specifications for each.

SEL-2505 Remote I/O Module | Schweitzer Engineering Laboratories

The SEL-2505 Remote I/O Module has eight digital inputs, eight digital outputs, and a fiber-optic communications port.

Fibre Channel

Fibre Channel (FC) is a high-speed data transfer protocol providing in-order, lossless delivery of raw block data. Fibre Channel is primarily used to connect computer data storage to servers in

Cisco Catalyst 2960-S and 2960 Series Switches with

Read this data sheet to learn the benefits, specifications, and ordering information for the Cisco Catalyst 2960 C Series Switches with LAN Lite Software.

Cisco 890 Series Integrated Services Routers Data Sheet

The 890 routers simplify the deployment of Ethernet WAN services, with end-to-end Operations, Administration, and Maintenance (OA&M), Service

Optical networks

An optical transport network is a high-speed communication system that sends light signals over fiber-optic cables to move large amounts of data across long

Semiconductor & System Solutions | Infineon Technologies

Infineon Semiconductor & System Solutions - MCUs, sensors, automotive & power management ICs, memories, USB, Bluetooth, WiFi, LED drivers, radiation h

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Contact Us

Continue your research online:

Website: https://bagyou.es
Technical inquiry: https://bagyou.es/project-enquiry.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.



© 2026 BAGYOU FIBRE NETWORKS - All rights reserved