Configuration to convert H3C switch optical port to electrical port

Overview

Chapter 1 Port Basic Configuration. H3C S5100-8P-SI, S5100You can specify a Combo port to operate as an electrical port or an optical port. That is, a Comb.

Key Takeaways

To configure an H3C switch Combo port with an optical-to-electrical adapter, you must select the active interface (optical or electrical), enable the port, and set speed and duplex parameters as needed. Understanding Combo PortsH3C switches often feature Combo ports, which can operate as either an optical (SFP) port or an electrical (RJ-45) port. Only one interface can be active at a time; enabling the optical port automatically disables the electrical port, and vice versa.

This ensures that the switch forwards traffic through a single physical interface.

Configuration Steps

Access the Switch CLIConnect via console, Telnet, or SSH to the switch. Enter system view: CodeCopysystem-view Enter the Interface ViewSpecify the interface number of the Combo port: CodeCopyinterface GigabitEthernet1/0/17 Replace 1/0/17 with the actual port number on your switch.

Select the Active Medium

For electrical (RJ-45) operation: CodeCopymdi auto orCodeCopymdi normal For optical (SFP) operation, ensure the SFP module is installed and the port is recognized. Optical interfaces do not support half-duplex or 10/100 Mbps settings; they operate in auto-negotiation mode by default.

© 2026 BAGYOU FIBRE NETWORKS · All rights reserved

Enable the Port

Bring the interface up: CodeCopyundo shutdown Set Speed and Duplex (Electrical Only)Optional for electrical ports: CodeCopyspeed autoduplex auto You can also specify full or half duplex if required. Enable Flow Control (Optional)To prevent packet loss during congestion: CodeCopyflow-control enable Flow control must be enabled on both ends of the link to be effective.

Verify the Port Status

Check the interface state: CodeCopydisplay interface GigabitEthernet1/0/17 Ensure the port shows up and the correct medium is active. Safety and Installation TipsESD Precautions: Wear an ESD wrist strap when handling SFP modules. Laser Safety: Do not look directly into optical fibers or SFP modules; they may emit invisible laser light.

Cable Handling: Maintain proper bend radius for fiber cables (at least eight times the cable diameter) to avoid damage. Dust Protection: Keep dust plugs on SFP ports until the module is installed.

Summary

When using an optical-to-electrical adapter on an H3C switch: Decide which interface (optical or electrical) will be active. Enter system and interface view, enable the port, and configure speed/duplex if electrical. Follow safety precautions for optical modules.

Verify the link is operational using the display interface command. This ensures proper operation of the Combo port and reliable network connectivity.

Article Content

Chapter 1 Port Basic Configuration. H3C S5100-8P-SI, S5100

You can specify a Combo port to operate as an electrical port or an optical port. That is, a Combo port cannot operate as both an electrical port and an optical port simultaneously.

H3C S1600V2 Switch Series Web Configuration Guide

Loop detection—When the system detects a loop on a port, it does not take any actions on the port, but it will display a red icon for the port on the port state pane.

H3C S5120-SI SERIES CONFIGURATION MANUAL Pdf Download

Follow these steps to log in to your H3C switch and enter the CLI through the console port: Use the console cable shipped with your switch to connect your PC to your switch. Page 17 Figure 1-3

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

H3C Switch Command Mastery: Streamlined Configuration

This article provides a hands-on guide to 50+ essential H3C switch commands, revealing hidden shortcuts and best practices derived from real-world deployments in Fortune 500 ...

H3C S6300 SERIES CONFIGURATION MANUAL Pdf Download

View and Download H3C S6300 Series configuration manual online. S6300 Series switch pdf manual download.

How to Master H3C Device Switch Commands: A Comprehensive Guide

Ready to optimize your network management? Explore our comprehensive guide to H3C device switch commands. Upgrade your skills and browse Router Switch for top-notch products now.

H3C S5830 Switch Series Configuration Examples

Configure GigabitEthernet 1/0/1 to implement MAC-based access control so each user is separately authenticated. When a user logs off, no other online users are affected. The

H3C Devices CLI Reference

If the device has a backup next-startup configuration file, execute the reset saved-configuration backup command to delete the backup next-startup configuration file.

H3C Switch Command Mastery: Streamlined Configuration

In today''s fast-paced network environments, H3C switches form the backbone of enterprise connectivity. While many administrators rely on GUI configurations, mastering CLI commands remains crucial for

04-Chapter 4 Connecting Your Switch to the Network

To configure and manage the switch through the console port, you must run a terminal emulator program, TeraTermPro or PuTTY, on your configuration terminal. You can use the emulator program

H3C Campus Fixed-Port Switches Web-Based Configuration Guide

Preface The H3C Campus Fixed-Port Switches Web-Based Configuration Guide describes the web functions of the H3C Campus Fixed-Port Switches, such as web overview, task fundamentals, and

How To Switch Optical/Electrical Mode On Huawei Router Combo Ports

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

This article takes the Huawei AR5710S-S8T2X router as an example to explain how to switch the optical and electrical modes of Combo ports. Figure 1 Schematic Diagram of Optical

H3C S5830 Switch Series Configuration Examples

The authentication port (UDP) used by RADIUS servers is 1812 according to standard RADIUS protocols. However, the port (UDP) is set to 1645 on an H3C device that functions as the

Switches-H3C

Products Data Center Switches Campus Network Switches AON Network Industrial Switches Data Center Switches Ultra-wideband, simple, and intelligent integration For intelligent ultra-wideband

Chapter 1 Port Basic Configuration. H3C S5100-8P-SI, S5100

Chapter 1 Port Basic Configuration 1.1 Ethernet Port Configuration 1.1.1 Combo Port Configuration A Combo port can operate as either an optical port or an electrical port. Inside the device there is only

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Contact Us

Continue your research online:

Website: https://bagyou.es
Technical inquiry: https://bagyou.es/project-enquiry.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved