How much circuit breaker is in the elevator distribution box



Overview

Elevator Feeder Wire Sizing GuideElevator controllers often have a maximum fuse or breaker size. The conductor can be larger for voltage drop, but the over.

Key Takeaways

Elevator distribution boxes typically use circuit breakers rated according to the elevator motor load, often ranging from 30 A to 400 A, with selective coordination required between upstream and downstream devices.

Typical Ratings and Types

Elevator distribution boxes house circuit breakers that protect the elevator motor, control circuits, and associated equipment. Common ampere ratings for elevator control switches and breakers include 30 A, 60 A, 100 A, 200 A, and 400 A, depending on the motor size and system voltage (208 V, 240 V, 480 V, or 600 V) as specified by manufacturers like Siemens. Breakers are usually thermal/magnetic (inverse-time) types to provide both overload and short-circuit protection.

Coordination and Safety

According to the National Electrical Code (NEC 620. 62), overcurrent devices in elevator disconnecting means must selectively coordinate with upstream feeders to ensure that only the affected circuit trips during a fault, preventing unnecessary shutdowns of other elevators or systems. This often requires two or more tiers of overcurrent protection, with branch breakers in the distribution box coordinated with upstream feeder breakers.

© 2026 BAGYOU FIBRE NETWORKS · All rights reserved

Selection Considerations

Motor Load: Breaker size should match the full-load current of the elevator motor, typically using the 80% rule for continuous loads. Type of Breaker: Solid-state soft starters may have built-in overload protection, so the distribution box breaker primarily provides short-circuit protection. Fuse Coordination: Some elevator systems use Class J fuses in the control switch, which must coordinate with upstream breakers for selective protection.

Future Expansion: Distribution boxes should leave space for additional breakers or upgrades, ensuring flexibility and safety.

Practical Example

For a 40 HP elevator motor, the feeder breaker might be rated around 1900 A for magnetic trip settings, while the branch breaker in the distribution box is sized to protect the motor and control circuits, typically documented by the manufacturer to ensure selective coordination. The exact rating depends on the motor voltage, type of starter, and system configuration. In summary, the circuit breaker in an elevator distribution box is selected based on motor load, system voltage, and NEC coordination requirements, with typical ratings ranging from 30 A to 400 A, using thermal/magnetic breakers or coordinated fuses to ensure safe and reliable operation.

Article Content

Elevator Feeder Wire Sizing Guide

Elevator controllers often have a maximum fuse or breaker size. The conductor can be larger for voltage drop, but the overcurrent device cannot exceed the equipment listing or the

Breakers used on an elevator switch

For the elevator switches up to 200-amps, the Series C type F Frame breaker is used. For the 400-amp switches, the Series G LG Frame breaker is used.

Elevator feeder and branch circuit | Information by Electrical ...

For high rise building, I have passenger elevator 30HP, FLA of 40A and freight elevator 40HP, FLA of 53A. Engineer used 430.52 to size the fused disconnect fuse and breaker in the panel.

Engineered Panels High Power Switches | Mersen

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

These panels are provided with a default short circuit current rating (SCCR) of 200kA and provide overcurrent protection through a combination of a circuit breaker and a fuse. The circuit breaker is

Emergency Standby Systems for Elevator Switches

devices are designed into standby systems and must be shown to coordinate. This publication provides the recommended circuit breaker and ratings that will selectively coordinate with the Mersen elevat

Panelboard | Elevator Control Panel | Eaton

Eaton''s Elevator Control panelboards provide electric power distribution with integrated fusible switches, metering, and surge protection. Additionally, they''re designed to meet UL 67 and NEMA PB1

Thyssenkrupp Elevator Electrical Specs | PDF | Elevator | Door

This document provides the electrical and civil requirements for a machine room and hoistway shaft for an elevator project. It lists 15 electrical details needed including items like power switches, circuit

Compliance with the 2017 NEC for Elevator Controllers

Hydraulic elevator installations are typically supplied from the main switchboard and have an elevator fused switch or circuit breaker in the machine room that serves as the elevator disconnect.

NEC Article 620 Elevators, Part 2

four categories for elevators and similar equipment, depending upon the nature of the specific equipment: For operating devices and control and signaling circuits, protection against overcurrent is

Elevator control PB panelboard design guide

Breaker ratings from 20 A to 600 A use unique drawout cassettes. Breakers are inserted and removed via a mechanical removal system similar to other drawout designs associated with switchgear;

Elevator motor overcurrent protection

There is an elevator with a 30hp 480v 3 phase motor. There is a 100 amp circuit breaker with a shunt trip in the elevator room. Based on 80 starts per hour, what is the minimum and

The Electrical Ups and Downs of Elevator Design | EC&M

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

The many codes and guidelines that regulate the electrical design of an elevator can seem overwhelming, and dealing with the electrical inspector, elevator inspector, and Fire Marshal

Elevator Breaker Size | Information by Electrical Professionals for ...

The elevator branch circuit OCPD device (per 620.61 (D)) would be sized per Article 430, Part IV. Per 430.53 (B), for a motor and additional load, the OCPD would be selected using table

0110-ElectricalRequirements-1124

Cab Light Power - 12/2 with Ground (min. 6”) Pigtail connected to house 20 Amp dedicated circuit. One (1) GFI Outlet separate from #2 elevator (120VAC) circuit. This should be on same circuit as #4. One

Elevator Circuit | Information by Electrical Professionals for ...

I have a 200 Amp breaker feeding a 200 Amp fused disconnect for an elevator. the elevator is a 25 HP 208 V 3 Phase. According to the motor table the FLA for sizing conductors and

Elevator Overcurrent Sizing | Information by Electrical Professionals ...

Re: Elevator Overcurrent Sizing Table 430.52 of NEC says that OCD for inverse time delay breakercan be sized to 250% of motor nameplate. 121 amps x250%= 302.5. This means that a

Elevator control PB panelboard design guide

Panelboards Overview Choices to quickly change feeder breakers in electrical distribution equipment have evolved over the years. While using drawout switchgear with power air circuit breakers remains

How to Determine the Number of Breakers in a Panel

How to Calculate the Number of Circuit Breakers for a Home Load Center and Distribution Board Based on the Load Calculation? In the USA and

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Contact Us

Continue your research online:

Website: https://bagyou.es
Technical inquiry: https://bagyou.es/project-enquiry.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.



© 2026 BAGYOU FIBRE NETWORKS - All rights reserved